


User manual CRS Online Edition



Contents



3 **CHAPTER 1: INTRODUCTION**

4 **CHAPTER 2: INSTALLATION**

4 Calling up CRS Online Edition

4 Calling up CRS Online Edition > Password management

5 Calling up CRS Online Edition with mission control system

5 **CHAPTER 3: SETTINGS**

5 General

6 Settings

7 **CHAPTER 4: VEHICLE SELECTION**

7 Manual vehicle selection

11 Request license plate number (RDW edition)

13 VIN request (RDW edition)

14 Current vehicle list

15 **CHAPTER 5: CRS RESCUESHEET**


20 **CHAPTER 6: OVERVIEW COMPONENTS**

27 **CHAPTER 7: WARRANTY**

28 **CHAPTER 8: LIABILITY**

Chapter 1

Introduction



Crash Recovery System Online Edition (CRS Online Edition), the vehicle information database for rescue workers around the world. Crash Recovery System Online Edition has been specifically designed for stationary users, such as in rescue coordination centres.

The Crash Recovery System supports emergency teams when rescuing people from vehicles involved in an accident. In just a few seconds, the system provides a complete overview of those safety systems that may put emergency teams and accident victims at risk during the rescue.

The system shows the position of safety and drive systems and provides important information on how to deactivate them. Having all of the necessary data immediately available can save valuable time for a successful rescue.

CRS Online Edition enables the user to easily transfer the type of vehicle via datasheet ID and generate vehicle information in PDF format.

Copyright © Moditech Rescue Solutions B.V.
Patents pending. All rights reserved.

Technical specifications / System requirements

Screen resolution:	At least 1024 x 768 pixels
Browser:	Internet Explorer 9 (and higher), Opera 9 (and higher), Firefox 54 (and higher), Safari 10 (and higher), Chrome 60 (and higher) Plug-ins Adobe SVG Viewer 3.0 (only for Internet Explorer 8) JavaScript must be enabled
Additional software:	Adobe Acrobat Reader 5 or higher
URL:	https://www.crashrecoveryssystem.com , https://www.crashrecoveryssystem.com (via port 433)

Update database


The CRS Online Edition database is updated automatically. A manual update is not required.

Support

Please contact us on support@moditech.com if you need help.

Chapter 2

Installation



Introduction

No software needs to be installed in order to use Crash Recovery System Online Edition. CRS Online Edition can therefore be run on any PC with access to the Internet. The system requirements (see technical specifications) must be met, and **access to the secured NdB network** with an authorised IP address is necessary. The IP address should start with **192.168.x.x**.

Calling up CRS Online Edition

Crash Recovery System Online Edition is launched by calling up the website <https://www.crashrecoveryssystem.com/crswebedition> in the Internet browser. Log on with the license code and corresponding password.

Login Crash Recovery System Online Edition



Login Name:

Password:

[Forgotten password?](#)

Calling up CRS Online Edition > Password management

If you don't have an administrator password yet or have forgotten your administrator password, you should **first create a new password for your administrator account via** https://www.crashrecoveryssystem.com/crswebedition/index.php?menu=password_forgotten.

You can then log in to the start screen of the online edition (<https://www.crashrecoveryssystem.com/crswebedition>) with your administrator name and newly saved password. Here you can change your **password for the Online Edition**.

With your **licence code** and newly saved password (**not** the administrator password) you can then log in to the online edition (<https://www.crashrecoveryssystem.com/crswebedition>).

Reset Administrator password

Enter your Moditech registered Administrator e-mail address. This e-mail address will be used to submit the required instructions.

Administrator e-mail address:

For support, please contact [Moditech Support](#)

Reset Administrator password

License code: 10740618

Administrator username: 10740618_admin

New Administrator password*: ⓘ

Confirm new password:

*. The password must be composed of at least 10 characters, and include at least one lowercase letter, one uppercase letter, one number and a special character: !#\$%&/'=?@_[]{}.

For support, please contact [Moditech Support](#)

Please note: We inform the system administrator of the password expiry. Only the system administrator is authorised to change the password of a CRS Online Edition.

The linked password should be renewed every 90 days. Enter your details and click "Save". Your password must be at least 10 characters long and contain at least one upper case letter, one lower case letter, one number and one special character !#\$%&/'=?@_[]{}.


The responsible system administrator can be forwarded to Moditech Rescue Solutions via support@moditech.com.

Calling up CRS Online Edition with mission control system

If you are using a mission control system such as ISE Cobra, DATUS, Scheusner, we recommend contacting your provider for an interface with our CRS Online Edition.


Chapter 3

Settings



General

When Crash Recovery System Online Edition is started, the home screen is displayed. In the top menu you can find helpful user information under the [General](#) button.



It is divided in [Service information](#) (Vehicle selection, CRS information sheet, System requirements, Support and FAQ), [Privacy](#) and [License agreement](#).

Vehicle selection How to select a vehicle, step by step.

CRS information sheet Explains the use of a CRS Rescuesheet.

System requirements Shows the hardware and software required to use this webapplication.

Support Shows contact information when you have problems or questions.


FAQ Here you can find the Frequently Asked Questions.

Privacy Important information about our privacy policy.

License agreement Here you can find the License Agreement between you and Moditech.

Settings

Settings in Crash Recovery System Online Edition can be modified under the menu item [Settings](#).



The following options for settings are available there:


- | | |
|------------------------------|--|
| CRS language | Select the language used in the vehicle graphics. |
| Auto Select | Automatically selects, in manual vehicle selection, provided that only one option is available in vehicle selection. |
| Worst Case | Automatically selects, in manual vehicle selection, the vehicle with all available options (model with question mark). Selection of engine type is not required. |
| OEM Datasheet-ID | Also shows the OEM datasheet ID in addition to the CRS datasheet ID. |
| ISO colour scheme | Select this option to use the official ISO colours in the vehicle datasheets. |
| License plate country | Selects the country to be used as a default for vehicle licence plate requests. |
| VIN country | Selects the country to be used as a default for VIN requests. |
| Start page | Select the preferred home page here. |
| Set as default | Sets these settings as default when starting CRS. |

Please note: Select [Save](#) to save the changes made to your settings.


Chapter 4

Vehicle selection


Manual vehicle selection




Select the database to be used for the vehicle selection. The available databases are divided into regions (e.g. [Europe](#) or [North-America](#)) and vehicle type ([Passenger vehicle](#), [Heavy duty truck](#), [Bus](#), [Special vehicles](#), [Campers](#), [Two wheelers](#) or [Agricultural vehicles](#)). The databases contain all vehicles currently or previously sold on the corresponding market and fitted with at least one (optional) airbag. A list of vehicle [manufacturers](#) is displayed:



After selecting the manufacturer (in this case BMW) a list of [available models](#) is displayed.




After selecting the [corresponding model](#), a list of available [engine types](#) is displayed. Select [?](#) if you are unsure of the engine type. The [?](#) shows the model with maximum options.




Please note: If the [Auto selection](#) option has been activated, then selection steps with only one option are automatically skipped.

In the next selection step, the **body design** must be selected.




The last selection step is the selection of the **model year**. Choose the right option and the CRS Rescuesheet will be immediately displayed.




Please note: You can return to an earlier vehicle selection step at any time by clicking a selection in the information bar. Example: From the BMW selection, return to the selection of possible BMW models.

If the selected vehicle is a model with hybrid, electric or hydrogen transmission, then an [information screen](#) is displayed (RDW Edition only). This screen contains important information on how to proceed with the vehicle.


Clicking the **X** button in the bottom right corner hides the information screen, and the selected vehicle can be seen.




If it is not a vehicle with hybrid, electric or hydrogen transmission, then the CRS Rescuesheet is immediately displayed. The vehicle selection using the manual selection procedure has been completed.



Request license plate number (RDW edition)



Select [Vehicle search](#) and [Licence plate](#) in the top left corner of the menu, to display a window where you can enter a [vehicle license plate number](#). Using the drop-down menu, the [country of origin](#) of the license plate can be specified.



Please note: Since the modification to vehicle registration legislation, interchangeable plates can be issued in Germany since 1 July 2012. This basically means that there is an interchangeable plate comprising an interchangeable element (which must be switched before the journey) and a fixed vehicle-specific part for each vehicle (see photo on next page). In the central vehicle register of the Federal Office for Motor Vehicles, the complete license number assigned to the vehicle is registered, comprising the common part and the vehicle-specific part.



Photo: GDV


In the example shown in the photo, two different license plate number requests are then possible, namely:

B VM 146 (common part) + 1 (vehicle-specific part) = **B VM 1461**

B VM 146 (common part) + 2 (vehicle-specific part) = **B VM 1462**


Press [Search](#) or the return key to start the vehicle license plate number request. A successful request displays the request result. If the data from the national vehicle register is not clear, then several options are proposed, if applicable. The data sheet ID is also displayed and can be communicated in a timely manner.

In the next selection step, the right [body design](#) must be selected.




If the selected vehicle is a model with hybrid, electric or hydrogen transmission, then an [information screen](#) is displayed (RDW Edition only). This screen contains important information on how to proceed with the vehicle. Clicking the **X** button in the bottom right corner hides the information screen, and the selected vehicle can be seen.


If it is not a vehicle with hybrid, electric or hydrogen transmission, then the CRS Rescuesheet is immediately displayed. The vehicle selection by requesting a licence plate has been completed.



VIN request (RDW edition)




Select [Vehicle search](#) and [VIN](#) in the top left corner of the menu to display a window where a vehicle identification number (VIN) can be entered. Using the drop-down menu, the VIN country of origin can be specified. Press [Search](#) or the return key to start the VIN request. The request result is presented in a manner similar to the [license plate number request](#).



Current vehicle list

Each CRS Rescuesheet that is requested in CRS Online Edition, is automatically added to the vehicle list. Select [Current vehicle list](#) in the top menu to display a list that allows you to switch quickly and easily between multiple, previously opened CRS Rescuesheets. The [Close vehicle](#) button in a CRS Rescuesheet closes the current selection, and the vehicle is no longer displayed in the Current vehicle list.




Chapter 5

CRS Rescuesheet

The vehicle image within the CRS Rescuesheet is an interactive image, unless you have a Lite Edition where the image is static. In all CRS editions, you can show or hide the roof, side and seats by clicking on the Show/Hide buttons. In addition, information on any component can be retrieved directly by clicking on it (CRS Online RDW Edition only).

All components are shown in their actual locations in the vehicle. General components applicable to the vehicle, such as bonnet opening, boot opening or steering column adjustment, are shown with icons on the left side of the CRS Rescuesheet. The operation of the CRS Rescuesheet is explained further in this chapter.



The displayed [CRS datasheet ID](#) facilitates communication between the CRS Online Edition user and CRS. The CRS datasheet ID can be sent wirelessly and entered in all versions of CRS. The associated vehicle is then selected directly. The [OEM datasheet ID](#) can also be displayed as an option, provided that it is available. The OEM datasheet ID can also be used for vehicle selection on a remote terminal.

Please note: The OEM datasheet ID is less precise and always refers to the vehicle with the maximum fittings. Situations may arise where a CRS datasheet ID is displayed, but there is no OEM datasheet ID.

Buttons

Two buttons are located under the information bar. The [Close vehicle](#) button closes the current selection. The vehicle is no longer displayed in the [Current vehicle list](#). The [Create CRS rescuesheet for CRS Viewer button](#) generates a PDF file containing the CRS Rescuesheet and all interactive information as well as the available photos. The PDF file will be generated in the background. When the file creation is complete, the (encrypted) PDF-file is automatically made available for 24 hours to local firebrigades using a CRSViewer.

To the right of the vehicle image that appears, several buttons are visible. The [Hide Roof](#), [Hide Side](#) and [Hide Seats](#) buttons can be used to show or hide parts of vehicles. After clicking, the buttons change colour. Hidden sections can be re-displayed by clicking the buttons again.

The [Deactivation](#) button is used for vehicles with alternative drives (e.g. hybrid cars). The [Fire](#) and [Submerged](#) buttons can be consulted when a vehicle is on fire or in water. With the [Show legend](#) button the legend, including an explanation of all component groups, can be displayed. For a complete overview with information on components, see [Chapter 6: Overview of Components](#).

Please note:

If the selected model is a vehicle with an alternative drive (electric or hybrid), when the CRS Rescuesheet is opened, the CRS immediately displays a warning screen with information on the type of drive.

By clicking on the [Cross icon](#) the warning screen disappears and the vehicle image appears.


The screenshot shows the web interface for crashrecoveryssystem.com. At the top, there is a navigation menu with categories like 'Vehicle search', 'Passenger vehicle', 'Heavy duty truck', 'Bus', 'Special vehicles', 'Campers', and 'Two wheelers'. Below the menu, the breadcrumb trail reads 'EU-car Selection >> BMW >> i8 >> ? >> Zdr coupe >> 2015-2020'. There are buttons for 'Close vehicle' and 'Create CRS rescuesheet for CRSViewer'. The main content area is dominated by a large red-bordered warning box with the following text:

Caution!
Plug-in Hybrid Electric Vehicle (PHEV). Combustion engine combined with electric motor and battery pack.
Lithium Ion (Li-Ion) battery pack.
Always assume the vehicle is powered, even if it is silent!
Make sure that the vehicle is immobilized and the propulsion system is deactivated (see Deactivation).
Never touch, cut, or open any orange high voltage power cable or high voltage component.
The body and body parts are made of carbon-fiber reinforced plastic.
While sawing in carbon-fiber reinforced plastic, carbon-fiber dust and little carbon-fiber fragments are given off, which could be health-threatening and/or dangerous for the occupant(s) and first responders. Use a FFP3 dust mask for protection.

At the bottom right of the warning box is a black 'X' icon. To the right of the warning box, there is a vertical column of buttons: 'Hide roof', 'Hide side', 'Hide seats', 'Show deactivation', 'Fire', 'Submerged', and 'Show legend'. The Moditech logo is visible at the bottom right of the interface. The footer contains the text 'powered by Moditech Rescue Solutions BV'.


Buttons > Hide roof

Select the **Hide roof** button and the roof of the vehicle, with all integrated components, is immediately hidden. This makes all components in the car clickable, such as airbags and the steering column. The roof is shown again after clicking the **Show roof** button.




Buttons > Hide side

The sides are shown and hidden with the **Hide side** and **Show side** buttons. The location of all components on the sides, such as the seat airbag, is now immediately clear. These can now also be clicked on.




Buttons > Hide seats

The seats are hidden with the [Hide seats](#) button. The location of all components on and under the base plate, such as the SRS sensor and the fuel tank, is now immediately clear. These can now also be clicked on. The seats are shown again after clicking the [Show seats](#) button.




Buttons > Show deactivation

In the vehicle image of an alternatively powered vehicle, the [Deactivation](#) button is present. When this button is selected, the screen with instructions on how to deactivate the vehicle appears. By clicking on the [Cross icon](#) or the [Deactivation](#) button the screen disappears and the vehicle image reappears.



Buttons > Show legend

The Show legend button displays an overview of the definitions of the colours used in the CRS vehicle image. By clicking on the [Cross icon](#) or the [Hide legend](#) button the screen disappears and the vehicle image reappears.




The screenshot shows the crashrecoveryssystem.com web application. The main navigation bar includes categories like 'Vehicle search', 'Passenger vehicle', 'Heavy duty truck', 'Bus', 'Special vehicles', 'Campers', and 'Two wheelers'. The current page is 'EU-car Selection >> BMW >> i8 >> 7 >> Zdr coupe >> 2015-2020'. A 'Legend' dialog box is open, listing various components and their corresponding colors:

Color	Component	Description
Red	Danger zone	Avoid these zones whenever possible.
Blue	Airbag	Airbag components.
Yellow	Electro	Electric or electronic (SRS) components.
Orange	Electro > 60V	Electric or electronic components > 60V.
Purple	Pretensioner	Belt pretensioner components.
Green	Miscellaneous	Miscellaneous components.
Teal	Reinforcement	Reinforcement components.
Light Blue	Glazing	Front, rear and side glazing.


On the right side of the legend dialog, there is a 'Close' button (represented by an 'X' icon) and a 'MODITECH RESCUE SOLUTIONS' logo. Below the legend dialog, there are several control buttons: 'Hide roof', 'Hide side', 'Hide seats', 'Show deactivation', 'Fire', 'Submerged', and 'Hide legend'. The footer of the page includes 'CRASH' logo, version information 'BM_16_06_00006 | v1.7 | DB: 01-Jul-2021-01', and 'powered by Moditech Rescue Solutions BV'.

Chapter 6


Overview of Components



Dangerzone




Dangerzone. The components **outlined in red** indicate components that are potentially dangerous during the rescue process.




Dangerzone driver and passenger airbag. Driver and passenger airbags outlined in **red indicate** dual stage airbags, whereby one stage may remain active after activation of the airbag. It also indicates a mechanical driver airbag which can be activated using mechanical force.


Airbag




Driver airbag




Stored gas inflator (for curtain airbags)




In dashboard: Passenger airbag
In seat: Anti-submarining airbag




Curtain airbag (Head impact)




Side impact airbag (Seat)



Knee-airbag driver




Side impact airbag (Side)




Knee-airbag passenger

Belt pretensioner



Belt pretensioner

Hydrogen



Gas (H₂)
pressure direction



Automatic hydrogen
overpressure safety valve
with gas type indication (H₂)




Gas line (H₂)



Gas tank with
gas type indication (H₂)




Manual gas
shut-off valve
with gas type indication (H₂)



Fuel cell component

Electronics > 30 V



Battery pack



Ultra-capacitor
(> 30 V)




Emergency disconnect
(Cut cable)




High voltage
power cable



Pantograph down
(buses only)




Fuse box disabling
high voltage




High voltage
component




Low voltage device that
disconnects high voltage



High voltage device that
disconnects high voltage



Special battery
access




Pantograph up
(buses only)


Electro




Sensor side/front




Sensor side/front (mechanical)




Battery (12 V)




Backup power- supply (if separate from SRS control unit. Ultra-capacitor (< 30 V)




Truck/Bus battery (24 V)




Start/Stop Button (Engine and Contact).
For trucks/buses engine only.




SRS control unit Roll bar control unit




Main battery switch




Seat occupancy sensor (if it can affect deployment of airbags)



Fuel warning indicator




Xenon lights




Solar panel


Seats



Front seat top view




Back seat top view




Front seat / back seat side view



Truck seat side view




Truck bed top view




Truck bed side view


Miscellaneous




Cylinder to support engine hood or trunk lid




Automatic roll bar




Fuel tank
(Petrol)



Fuel tank
(Miscellaneous)




Fuel tank
(Diesel)



Hydraulic oil




Air tank




Air intake (truck/bus)



Engine hood opening
(hood opening to the rear)



Trunk lid opening



Chargeplug



Seat adjustment



Steering wheel tilt



Lifting points




Grill opening (truck)




Seat height adjustment by air
(truck/bus)



Height control (truck)




Height control (bus)



Emergency
door release



Carbon-fiber
reinforced plastic



Pedestrian protection system




Remove smart key/
starter key



Emergency exit
right hand




Break to obtain access



Cabin suspension
(trucks only)



Driver rest area
(buses/coaches only)



Power Take-Off (PTO)
(tractors only)



Gas line
(generic)



Gas tank with gas type
indication (CNG)




Automatic gas overpressure
safety valve with gas type indication
(CNG)



Automatic fire suppression



Emergency exit
left hand



Emergency door opener




Emergency exit roof hatch
(buses/coaches only)




Cabin tilting
(trucks only)



Toilet cabin
(buses/coaches only)




Nitrogen gas bulbs
(tractors only)



Gas pressure
direction



Manual gas shut-off valve
with gas type indication (CNG)



Gas tank with gas type
indication (LPG)




Manual gas shut-off valve with gas type indication (LPG)



Automatic gas overpressure safety valve with gas type indication (LPG)



Gas tank with gas type indication (DME)



Manual gas shut-off valve with gas type indication (DME)



Automatic gas overpressure safety valve with gas type indication (DME)



Gas tank with gas type indication (LNG)




Manual gas shut-off valve with gas type indication (LNG)




Automatic gas overpressure safety valve with gas type indication (LNG)

Air conditioning




Air conditioning component




Air conditioning line

Glazing



Glazing, glass or plastic, tempered or laminated

Reinforcement



Reinforcement components in bodywork


Road Assist Edition



Automatic gearbox



Recovery




Jump-starting



Electric parking brake




On-board diagnostics



Inertia switch

Chapter 7

Warranty




In the event that the CRS software does not function properly after it has been put into operation due to a manufacturing or material defect, the Licensee shall be entitled to call upon the warranty, provided that the defect was not caused by improper use of the software.

This user manual is an integral part of the Licence Agreement and the General Terms and Conditions of Moditech Rescue Solutions B.V. For other warranty provisions, please refer to the General Terms and Conditions of Moditech Rescue Solutions B.V. and the Licence Agreement.

Chapter 8

Liability



The images and information in the CRS were obtained and compiled from reliable sources within the automotive industry.

Moditech Rescue Solutions B.V. has made every effort to ensure that this data is correct and corresponds to the selected vehicle models, but selection errors, production modifications, mistakes or missing items may occur.

Moditech Rescue Solutions B.V. does not claim any liability and can also not be held liable for physical or material damage or loss as a result of one or more of the aforementioned causes.

The liability of Moditech Rescue Solutions B.V. for damage suffered by the Licensee, irrespective of the basis for such damage, shall at all times be limited to a maximum amount equivalent to the licence fee paid by the Licensee under the Licence Agreement.


The liability of Moditech Rescue Solutions B.V. for indirect or consequential damage is excluded.

The Licensee can only claim compensation for damage as referred to in the above article if it was caused by an attributable shortcoming or wrongful act on the part of Moditech Rescue Solutions B.V., and if, after having been duly served with a notice of default by the Licensee, the shortcoming has not been remedied within a reasonable period.

The Licensee must follow the instructions contained in this User Manual when using the software. Any use other than described in the user manual of the regulations mentioned here or failure to implement these regulations in the correct order can never lead to Moditech Rescue Solutions B.V. being held liable.

If the software has not been updated to the most recent version, Moditech Rescue Solutions B.V. excludes all liability.

Any claim by the Licensee will lapse if it has not been filed within one year after the cause of which could have reasonably been known. All claims by the Licensee are subject to the jurisdiction of and must be filed with the courts in Alkmaar, the Netherlands.



Know what's inside.
Act with confidence.



www.moditech.com